

# SUBWOOFER MANUAL

EDP122-E6

EDP122SPL-E6

EDP152SPL-E6

### **OWNERS MANUAL**

Congratulations on purchasing your EDGE subwoofer. Please read this manual in order to fully understand how to get the best results from this product and ensure that all advice on how to look after the product is followed.

Thank you for buying EDGE, we hope you enjoy listening to your product as much as we enjoyed creating it.

### **CAUTION**



DO NOT EXPOSE THIS PRODUCT TO DAMP OR MOISTURE - doing so may result in fire, shock or damage to the product.

BEFORE WIRING DISCONNECT THE CABLE FROM THE POSITIVE BATTERY TERMINAL - failure to do so may result in electric shock or injury.

**ENSURE GOOD AND CORRECT CONNECTIONS** - failure to make the correct connections may result in fire or damage to the product.

DO NOT USE ANY FUNCTIONS OF THIS EQUIPMENT THAT MAY TAKE YOUR CONCENTRATION AWAY FROM DRIVING YOUR VEHICLE - do not set up your amplifier whilst driving, doing so may result in an accident. For prolonged setting up, make sure that your vehicle is stationary and in a safe location.

KEEP THE VOLUME AT A LEVEL SO YOU CAN STILL HEAR OUTSIDE NOISE - failure to do this may result in an accident. EDGE equipment is capable of producing sound levels that can permanently damage your hearing. EDGE recommends caution when listening at high volume. For safe and enjoyable listening the sound should be comfortable and clear without distortion.

#### CAUTION

Never connect any speaker lead to the car chassis. This can cause severe damage to your speaker /car radio /amplifier.

Before drilling or cutting any holes, investigate the layout of your vehicle thoroughly.

Use caution when working near the fuel / hydraulic lines and electrical wiring.

Observe the correct polarity when wiring, improper phasing may cause a loss of bass response. Ensure that no moving parts catch on the speaker or grill (e.g. window or door handles, or window glass inside the door)

## INSTALLATION

- The quality of the installation will affect the system performance and reliability.
- Contact your nearest authorised EDGE dealer if you are unsure about the installation of this
  product.
- Please mount this unit away from any potential hazards.
- Minimising the length of wires will provide higher audio output from the system.
- The speaker should be securely fastened to the mounting position using the screws provided.
- Pre drill your mounting holes using a drill and position with the template provided.
- Be sure to investigate your mounting area thoroughly for electrical wires, brake or fuel lines or fuel tank to prevent causing any damage.

### LIMITED WARRANTY

All EDGE products carry a full 12 month warranty, valid from the date of the original receipt and proof of purchase. It is recommended that the online warranty card is completed within seven days of the original purchase date and the original receipt and packaging should be retained. If the product develops a problem any stage during the warranty period, it should be returned to the point of purchase in it's original packaging, and complete with no items missing. If the store is unable to repair the product it may have to be returned to EDGE.

A full description of EDGE warranty information can be found on our website:

## www.edgecaraudio.com/warranty

### WHAT IS NOT COVERED

- Damage to product due to improper installation.
- · Subsequent damage to other components.
- Damage caused by exposure to moisture, excessive heat, chemical cleaners and / or UV radiation.
- Damage through negligence, misuse, accident or abuse. Repeated returns for the same fault may be considered abuse.
- Any cost or expense related to the removal and / or re-installation of the product.
- · Damage caused by amplifier clipping or distortion.
- · Items repaired or modified by any unauthorised repair facility.
- · Return shipping on non defective items.
- Products returned without a returns authorisation number.
- · Damage to product due to use of sealant.

#### INTERNATIONAL WARRANTY

Contact your international EDGE dealer or distributor concerning specific procedure for your country's warranty policies. www.edgecaraudio.com

#### WARNING

EDGE equipment is capable of sound pressure levels that can cause permanent damage to your hearing and those around you. Please use common sense when listening to your audio system and practice safe sound.

#### COPYRIGHT

All content included in this manual such as text, graphics, logos, icons, images and data, are the property of Midbass Distribution Limited Va EDGE audio (herein referred to as "EDGE", "as" or "we") and its affiliate or their content and technology providers, and are protected by United Kingdom and International copyright laws. All rights reserved. EDGE and all stylised representations of product names, or the abbreviations of product names, as logos are all trademarks of EDGE. Graphics and logos are trademarks or trade dress of EDGE audio or its subsidiaries. EDGE's trademarks and trade dress may not be used in connection with any product or service that is not EDGE's, in any manner that is likely to cause confusion among oustomers or in any manner that disparages or discredits EDGE. All other trademarks not owned by EDGE or its subsidiaries that aposition in this manual are the property of their respective owners, who may or may not be affiliated with, connected to, or sponsored by EDGE or its subsidiaries.

TO THE FULLEST EXTÉNT PERMITTED AT LAW. EDGE IS PRÓVIDING THIS MANUAL AND ITS CONTENT ON AN 'AS IS' BASIS AND MAKES NO (AND EXPRESSEY) DISCLAMS ALL) REPRESENTATIONS OR WARRANTIES OF ANY KIND, EXPRESS OR MURILED, WITH RESPECT TO THIS MANUAL OR THE INFORMATION, CONTENT, MATERIALS OR PRODUCTS INCLUDED IN THIS MANUAL INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN ADDITION, EDGE DOES NOT REPRESENT OR WARRANT THAT THE INFORMATION CONTAINED IN THIS MANUAL IS COMPLETE OR CURRENT, AND THAT LLI SPECIFICATIONS AND INFORMATION CONTAINED WITHIN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. EDGE RECOMMEND CAUTION WHEN LISTENING TO MUSIC REPRODUCED THROUGH EDGE EQUIPMENT. EDGE EQUIPMENT IS CAPABLE OF PRODUCING SOUND AND SOUND PRESSURE LEVELS THAT CAN PERMANENTLY DAMAGE HEARING OF YOU AND THAT OF OTHERS. FOR SAFE AND ENJOYABLE LISTENING, THE SOUND SHOULD BE CLEAR WITHOUT DISTORTION AT A COMFORTABLE VOLUME. BY USING ANY EDGE EQUIPMENT, YOU AGREE TO TAKE FULL RESPONSIBILITY FOR YOUR OWN SAFETY AND THE SAFETY OF OTHERS WHEN LISTENING TO MUSIC AT HIGH VOLUMES THROUGH EQUIPMENT YOU HAVE PURCHASED. USE OF ANY EDGE EQUIPMENT YOUTS DESCLAMER.

Except as specifically stated in this manual, to the fullest extent permitted at law, neither EDGE nor any of its affiliates, directors, employees or other representatives will be liable for damages arising out of or in connection with the use of this manual or the information, content, materials or products included.

This is a comprehensive limitation of liability that applies to all damages of any kind, including (without limitation) compensatory, direct, indirect or consequential damages, loss of data, income or profit, loss of or damage to property and claims of third parties. For the avoidance of doubt, EDGE does not limit its liability for death or personal injury to the extent only that it arises as a result of negligence of EDGE, its affiliates, directors, employees or other representatives.

### **RUN IN PROCEDURE**

EDGE recommends that you follow the run in procedure for the subwoofer detailed below.

When your subwoofer is used for the first time, like most brand new items it is naturally very stiff and rigid. It will take time for the moving parts of this subwoofer to loosen up before the subwoofer will be ready to deliver its full potential.

For the first thirty hours it is recommended that you play the subwoofer at low to medium volumes, gradually increasing the volume level as time

progresses. As a guide, if you listen to your subwoofer for one hour every day it will take a month for the subwoofer to run in properly.

You will notice a big change in the sound of the subwoofer over this period. As the spider and surround begin to run in the sound will get deeper and harder, also the output of the subwoofer will increase as the suspension loosens up.

The subwoofer is like your car's engine, it needs a few thousand miles before you can drive it to its full potential. Driving it into the redline from the first day will mean engine damage is certain and will not be covered by warranty.


Failure to follow this simple procedure is the most common reason for a subwoofer to fail after a very short period of time.


### **TS PARAMETERS**

Parameter	EDP122SPL-E6	EDP122-E6	EDP152SPL-E6
Recv	3.6 Ohm	3.6 Ohm	4 Ohm
F0	37.5Hz	49.5Hz	40.2Hz
SD	47.144	47.144	73.062
Mmd	250g	250g	250g
BL	21.98 TM	27.22TM	29.895 TM
Qms	6.667	5.668	0.066
Qes	0.587	0.506	0.543
Qts	0.539	0.464	0.499
N0	0.148%	0.226%	0.286%
SPL	83.7dB	85.6dB	86.6dB
Vas	17.020 mm2	9.739 mm2	24.728 mm2
Cms	53.928 uM/N	30.,860 uM/N	32.622 uM/N
Krm	14.211 mOhm	17.289 mOhm	24.860 mOhm
Erm	0.830	0.805	0.799
Mms	334.435g	334.435g	480.851g
Mmd	328.550	328.550	469.496
Kxm	101.433mH	140.877	190.618mH
Exm	0.645	0.600	0.593

# **WIRING CONNECTIONS**

Please follow the wiring diagram below and ensure that correct polarity is observed as incorrect wiring may cause the subwoofer to be out of phase with the rest of the system and result in a loss of bass.






# **SPECIFICATION**

Model	EDP122SPL-E6	EDP122-E6	EDP152SPL-E6
Туре	Subwoofer	Subwoofer	Subwoofer
Speaker Size	12"" (322mm)	12"" (322mm)	15" (392mm)
RMS Power	1500 watts	2500 watts	4000 watts
Peak Power	4500 watts	7500 watts	12000 watts
Minimum Input (RMS)	750 watts	1250 watts	2000 watts
Sensitivity	83.7dB	85.6dB	86.6dB
Frequency Response	25Hz - 1500Hz	25Hz - 1500Hz	20Hz - 850Hz
Impedance	Dual 2Ω	Dual 2Ω	Dual 2Ω

## **DIMENSIONS**



## **UK TECHNICAL ENQUIRIES**

### Call 09067031420

Calls cost 50p per minute. Call costs correct at date of publication (01/02/12) Hours of business 9.00am - 5.30pm GMT Monday - Friday. All calls are recorded for training purposes. MIDBASS Distribution PO Box 11000 B75 7WG



# **INTERNATIONAL TECHNICAL ENQUIRIES**

For international technical support please contact the distribution agent for your country. Please visit **www.edgecaraudio.co.uk** for more details.







www.edgecaraudio.com



www.facebook.com/edgeaudio